

AUKEY

User Manual
Twe Wireless Earbuds

Aukey Technology Co., Ltd.
www.aukey.com | info@aukey.com
Building 608, South China City Electronics Building Center,
Longgang District, Shenzhen, Guangdong, 518111, China
KCC 20 2448484

CE RoHS

Thank you for purchasing the AUKEY EP-N5 Two Wireless Earbuds. Please read the user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

Package Contents

- 1 x Two Wireless Earbuds
- 1 x USB-C to USB (5A/M)
- 1 x USB-C to C Cable
- 1 x Quick Start Guide
- 1 x User Manual
- 1 x Warranty Card

Product Diagram

Specifications

Model	EP-N5
Technology	BT 5.2, A2DP, HFP, HSP, AVCP
Driver (each channel)	1 x 10mm / 0.5" speaker driver
Sensitivity	100dB ±3dB
Frequency Range	20Hz - 20kHz
Impedance	32Ω
Microphone Type	MEMS (with Microphone Chip)
Microphone Sensitivity	-42dB ±1dB
Microphone Response Range	20Hz - 8kHz
Charging Time	1.5 hours
Battery Life	Up to 10 hours
Charging Case	Up to 30 hours (ANC off)
Charging Range	10m / 33ft
Weight	10g / 0.35oz

Charging Case

Charging Time	2.0 hour
Charging Time	1.5 hours (300mAh)
Number of Earbuds Recharges	4 times (full)
Weight	41g / 1.43oz

Getting Started

Charging

Charge the charged case before first use. Connect the charging case to a USB charger or charging port with the included USB-A to C cable. When all LED charging indicator lights are green, the case is fully charged. Charging takes around 2 hours, and after being fully charged, the case can fully charge the earbuds 4 times. The earbuds always charge in the case when not in use. When the earbuds are charging in the case, the case will not charge. The LED indicator on the earbuds will turn red when the earbuds are not fully charged.

Turning On / Off

Turn on / Off the lid of the charging case.
Turn off / Put the earbuds back in the charging case and close the lid.

Pairing

Put the earbuds in the case.
Open the lid of the charging case. Both earbuds will turn on automatically and will automatically pair with the included USB-A to C cable. When all LED charging indicator lights are green, the case is fully charged. Charging takes around 2 hours, and after being fully charged, the case can fully charge the earbuds 4 times. The earbuds always charge in the case when not in use. When the earbuds are charging in the case, the case will not charge. The LED indicator on the earbuds will turn red when the earbuds are not fully charged.

Regular Use After Pairing

Once the earbuds are successfully paired with your device, they can be used with each other automatically.

Open the lid of the charging case. Then both earbuds will turn on and connect with each other automatically.

Turn on / Off the lid of the charging case and close the lid. The earbuds will be in charging mode.

Clearing the Pairing List

Make sure both earbuds are off and in the charging case. Take one of the earbuds out.
1. Turn on the touch-sensitive panel 5 times, and then the earbud will enter pairing mode (blue light will flash) and the charging case, and the lid will close when you open it for the first time.
2. Turn on the touch-sensitive panel 7 times to close the previous pairing list, and the earbud will turn off.

Using the Left/Right Earbud Only

Start with the earbuds in the case.
1. Turn on the pairing function on the device you want to pair with the earbud from the lid of the earbuds. Connect, find and select "AUKEY EP-N5".
2. Turn on the lid of the charging case, and the earbuds will turn on automatically and will be in charging mode.

Notes

When you turn on the earbuds, they will automatically reconnect to the last paired device or area you used most. Both earbuds will turn on automatically and will automatically pair with the included USB-A to C cable. When all LED charging indicator lights are green, the case is fully charged. Charging takes around 2 hours, and after being fully charged, the case can fully charge the earbuds 4 times. The earbuds always charge in the case when not in use. When the earbuds are charging in the case, the case will not charge. The LED indicator on the earbuds will turn red when the earbuds are not fully charged.

Control & LED Indicators

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Charging Case

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

LED Indicator (Earbuds)

Flashing green (red)	Status
Flashing green	Flashing mode
Flashing red	Flashing mode
Flashing red	Flashing mode
Flashing green	Flashing mode
Flashing green	Flashing mode

LED Charging Indicator (Charging case)

Flashing green	Status
Flashing green	Charging
Flashing green	Full charging
Flashing green	Full charging

Warning

Top the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

LED Indicator (Earbuds)

Flashing green (red)	Status
Flashing green	Flashing mode
Flashing red	Flashing mode
Flashing red	Flashing mode
Flashing green	Flashing mode
Flashing green	Flashing mode

LED Charging Indicator (Charging case)

Flashing green	Status
Flashing green	Charging
Flashing green	Full charging
Flashing green	Full charging

FAQ

The earbuds are on, but not connecting my device
Adjust the volume on your smartphone and the earbuds. Make sure the earbuds are fully charged and the case is fully charged. Make sure the earbuds are in the case when not in use. When the earbuds are charging in the case, the case will not charge. The LED indicator on the earbuds will turn red when the earbuds are not fully charged.

I've connected the earbuds with my smartphone but can't hear any sound
Double-check the volume level on your smartphone and the earbuds. Make sure the earbuds are fully charged and the case is fully charged. Make sure the earbuds are in the case when not in use. When the earbuds are charging in the case, the case will not charge. The LED indicator on the earbuds will turn red when the earbuds are not fully charged.

The sound isn't very clear or the call can't hear my voice clearly
Adjust the volume on your smartphone and the earbuds. Make sure the earbuds are fully charged and the case is fully charged. Make sure the earbuds are in the case when not in use. When the earbuds are charging in the case, the case will not charge. The LED indicator on the earbuds will turn red when the earbuds are not fully charged.

What's the wireless range of the earbuds?
The maximum range is 30m (100'). However, the actual range depends on environmental factors. For optimal performance, keep your device connected with a range of 10m to 30m and make sure that there are no major obstacles that may block the signal between the earbuds and your device.

Can I use the earbuds in the shower, bath, or pool?
No, the earbuds are not waterproof and should not be used in water.

Can I use the earbuds with a car stereo or other audio equipment?
Yes, the earbuds are compatible with most audio equipment.

Product Care & Use

Keep away from liquids and extreme heat.
Do not leave the earbuds or charging case for extended periods, as this may cause permanent damage to the product.

Warranty & Customer Support

For warranty and customer support information, visit the website below that corresponds with your region. Please include your Amazon order number and product model number.

Amazon US sales: support@aukey.com
Amazon EU sales: support@aukey.com
Amazon IN sales: support@aukey.com
Amazon JP sales: support@aukey.com

FCM Information for Users

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. The device must not cause harmful interference.
2. The device must accept any interference received, including interference that may cause undesired operation.

CE Statement

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. The device must not cause harmful interference.
2. The device must accept any interference received, including interference that may cause undesired operation.

CAUTION: RISK OF BATTERY FIRE & EXPLOSION IF BATTERY IS INCORRECTLY INSERTED. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Technical Data

Model	EP-N5
Technology	BT 5.2, A2DP, HFP, HSP, AVCP
Driver (each channel)	1 x 10mm / 0.5" speaker driver
Sensitivity	100dB ±3dB
Frequency Range	20Hz - 20kHz
Impedance	32Ω
Microphone Type	MEMS (with Microphone Chip)
Microphone Sensitivity	-42dB ±1dB
Microphone Response Range	20Hz - 8kHz
Charging Time	1.5 hours
Battery Life	Up to 10 hours
Charging Case	Up to 30 hours (ANC off)
Charging Range	10m / 33ft
Weight	10g / 0.35oz

Charging Case

Charging Time	2.0 hour
Charging Time	1.5 hours (300mAh)
Number of Earbuds Recharges	4 times (full)
Weight	41g / 1.43oz

Votre produit est livré avec le chargeur sans fil pour les écouteurs sans fil AUKEY EP-N5. Veuillez lire attentivement le manuel de l'utilisateur et le garder pour référence future. Si vous avez besoin de conseils, veuillez contacter notre équipe de soutien client avec le numéro de modèle et votre numéro de commande Amazon.

Contenu de l'emballage

- 1 x Deux écouteurs sans fil
- 1 x Câble USB-C à USB (5A/M)
- 1 x Câble USB-C à C
- 1 x Guide de démarrage rapide
- 1 x Manuel de l'utilisateur
- 1 x Carte de garantie

Produit

Technische Daten

Modell	EP-N5
Technologie	BT 5.2, A2DP, HFP, HSP, AVCP
Treiber (je Kanal)	1 x 10mm / 0,5" Lautsprecher
Empfindlichkeit	100dB ±3dB
Frequenzbereich	20Hz - 20kHz
Impedanz	32Ω
Mikrofontyp	MEMS (mit Mikrofonchip)
Mikrofonempfindlichkeit	-42dB ±1dB
Mikrofonfrequenzbereich	20Hz - 8kHz
Ladungszeit	1,5 Stunden
Batterielebensdauer	Bis zu 10 Stunden
Ladungsreichweite	Bis zu 30 Stunden (ANC aus)
Reichweite	10m / 33ft
Gewicht	10g

Lade-Case

Ladungszeit	2,0 Stunden
Ladungszeit	1,5 Stunden (300mAh)
Anzahl der Aufladungen der Ohrhörer	4-mal (vollständig)
Gewicht	41g

Erste Schritte

Laden Sie den Ladebehälter vor dem ersten Gebrauch vollständig auf. Schließen Sie den Ladebehälter mit dem eingeschlossenen USB-A-zu-C-Kabel an ein USB-Ladegerät oder einen Ladegerät an. Wenn alle LED-Ladungsindikatoren grün leuchten, ist das Case vollständig geladen. Das Ladegerät kann bis zu viermal die Ohrhörer aufladen. Die Ohrhörer laden immer im Case, wenn sie nicht in Gebrauch sind. Wenn die Ohrhörer im Case geladen werden, wird das Case nicht geladen. Die LED-Indikatoren auf den Ohrhörern werden rot, wenn die Ohrhörer nicht vollständig geladen sind.

Normale Verwendung nach dem Pairing

Wenn die Ohrhörer mit Ihrem Gerät erfolgreich verbunden sind, können Sie sie auch einzeln verwenden.

Verwendung nur des linken/rechten Ohrhörers

Beginnen Sie mit dem Pairing der Ohrhörer mit dem Gerät, das Sie verwenden möchten. Öffnen Sie den Deckel des Lade-Cases und stecken Sie die Ohrhörer ein. Schließen Sie den Deckel. Das Ladegerät wird automatisch eingeschaltet und die Ohrhörer werden in den Lade-Case mit eingeschlossen. Schließen Sie den Deckel. Das Ladegerät wird automatisch eingeschaltet und die Ohrhörer werden in den Lade-Case mit eingeschlossen. Schließen Sie den Deckel.

Ein-/Ausstecken

Öffnen Sie den Deckel des Lade-Cases.
Ausstecken: Öffnen Sie den Deckel des Lade-Cases und stecken Sie die Ohrhörer ein. Schließen Sie den Deckel.

Notes

When you turn on the earbuds, they will automatically reconnect to the last paired device or area you used most. Both earbuds will turn on automatically and will automatically pair with the included USB-A to C cable. When all LED charging indicator lights are green, the case is fully charged. Charging takes around 2 hours, and after being fully charged, the case can fully charge the earbuds 4 times. The earbuds always charge in the case when not in use. When the earbuds are charging in the case, the case will not charge. The LED indicator on the earbuds will turn red when the earbuds are not fully charged.

Steuerungstasten & LED-Anzeigen

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Steuerungstasten & LED-Anzeigen

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Steuerungstasten & LED-Anzeigen

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Steuerungstasten & LED-Anzeigen

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Steuerungstasten & LED-Anzeigen

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Steuerungstasten & LED-Anzeigen

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Steuerungstasten & LED-Anzeigen

Shimmering Audio

Touch the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.
Tap the touch-sensitive panel on either earbud to answer or end a call, and touch and hold for 2 seconds to end the call.
Repeat an incoming call.

Play or pause Tap the touch-sensitive panel on either earbud.
Stop track / next Double-tap the touch-sensitive panel on the right earbud.
Volume up/down Touch the touch-sensitive panel on either earbud.
Active Noise Cancelling Active noise cancelling functionality requires the use of both earbuds.
Turn on/off Touch and hold the touch-sensitive panel on the left or right earbud for 2 seconds to turn on/off the noise cancellation function.

Merci d'avoir acheté le chargeur sans fil pour les écouteurs sans fil AUKEY EP-N5. Veuillez lire attentivement le manuel de l'utilisateur et le garder pour référence future. Si vous avez besoin de conseils, veuillez contacter notre équipe de soutien client avec le numéro de modèle et votre numéro de commande Amazon.

Contenu de l'emballage

- 1 x Deux écouteurs sans fil
- 1 x Câble USB-C à USB (5A/M)
- 1 x Câble USB-C à C
- 1 x Guide de démarrage rapide
- 1 x Manuel de l'utilisateur
- 1 x Carte de garantie

Produit

Características Técnicas

Modelo	EP-N5
Tecnología	BT 5.2, A2DP, HFP, HSP, AVCP
Conductor (por canal)	1 x 10mm / 0,5" altavoz
Sensibilidad	100dB ±3dB
Rango de frecuencias	20Hz - 20kHz
Impedancia	32Ω
Tipos de micrófono	MEMS (con chip de micrófono)
Sensibilidad del micrófono	-42dB ±1dB
Rango de frecuencia del micrófono	20Hz - 8kHz
Tiempo de carga	1,5 horas
Autonomía de la batería	Hasta 10 horas
Tiempo de carga del cargador	Hasta 2 horas
Alcance de transmisión	Hasta 30 horas (ANC apagado)
Peso	10g

Caja de carga

Tiempo de carga	2,0 horas
Tiempo de carga	1,5 horas (300mAh)
Número de recargas de los auriculares	4 veces (total)
Peso	41g

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Primeros pasos

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Gracias por comprar AUKEY EP-N5 Auriculares inalámbricos. Por favor, lea atentamente el manual de usuario y guárdelo para referencia futura. Si necesita cualquier consejo, póngase en contacto con nuestro equipo de servicio con su número de modelo y número de pedido de Amazon.

Contenido del Paquete

- 1 x Dos auriculares inalámbricos
- 1 x Cable USB-C a USB (5A/M)
- 1 x Cable USB-C a C
- 1 x Guía de inicio rápido
- 1 x Manual de usuario
- 1 x Tarjeta de garantía

Diagrama del producto

Especificaciones Auriculares

Modelo	EP-N5
Tecnología	BT 5.2, A2DP, HFP, HSP, AVCP
Conductor (por canal)	1 x 10mm / 0,5" altavoz
Sensibilidad	100dB ±3dB
Rango de frecuencias	20Hz - 20kHz
Impedancia	32Ω
Tipos de micrófono	MEMS (con chip de micrófono)
Sensibilidad del micrófono	-42dB ±1dB
Rango de frecuencia del micrófono	20Hz - 8kHz
Tiempo de carga	1,5 horas
Autonomía de la batería	Hasta 10 horas
Tiempo de carga del cargador	Hasta 2 horas
Alcance de transmisión	Hasta 30 horas (ANC apagado)
Peso	10g

Caja de Carga

Tiempo de carga	2,0 horas
Tiempo de carga	1,5 horas (300mAh)
Número de recargas de los auriculares	4 veces (total)
Peso	41g

Inicio rápido

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Inicio rápido

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Inicio rápido

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido en el paquete de carga. Cuando todos los LEDs de carga del estuche de carga estén verdes, el estuche de carga está completamente cargado. El cargador puede cargar hasta cuatro veces los auriculares. Los auriculares siempre se cargan en el estuche de carga cuando no están en uso. Cuando los auriculares se cargan en el estuche de carga, el estuche de carga no se cargará. Los indicadores LED de los auriculares se volverán rojos cuando los auriculares no estén completamente cargados.

Mise en marche / Arrêt

Mettre en marche: Ouvrez le couvercle du boîtier de chargement.
Arrêt: Fermez le couvercle du boîtier de chargement.

Inicio rápido

Cargue completamente el estuche de carga antes de primer uso. Conecte el estuche de carga con el cable USB-A a C incluido