




Contents
English 01-19
Deutsch 19-27
Français 27-33
Español 33-34
Italiano 37-44
Dutch 44-48



Thank you for purchasing the AUKEY EP-B22 Wireless Headphones. Please read the user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

Package Contents
Wireless Headphones
Micro USB Cable
3.5mm Audio Cable
Carrying Pouch
User Manual



Specifications
Model: EP-B22
Technology: BT 5.2, A2DP, HFP, HSP, AVRCP, GATT
Driver (each channel): 40mm x 13.5" speaker driver





Getting Started
Fully charge your headphones before first use. Before charging, make sure the headphones are turned off. To charge, simply connect one end of the micro USB cable to a USB charging port, and the other end to the host port on the headphones. When the red charging indicator is lit, your headphones are fully charged and ready to use. Charging takes about 2 hours.





Simultaneous Pairing with Two Devices
1. Press and hold the multi-function button to pair the headphones with Device A.
2. Once paired, turn off Device A and turn on the headphones. Follow the instructions in the "Pairing" section to pair with Device B.
3. Once the pairing is complete, you'll hear a "Pairing" voice notification and the headphones will automatically enter pairing mode.




Music and Calls Control
The headphones feature touch-sensitive controls for music and calls. To use these controls, simply touch the designated areas on the earcups. For example, a double tap on the left earcup will play/pause music, and a single tap will answer a call.










FAQ
The headphones are on, but not connecting to my device.
Answer: Please check the Bluetooth settings on your device and ensure the headphones are in pairing mode. Also, make sure the device is within the Bluetooth range.











CE Statement
This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.










Specifications
Model: EP-B22
Technology: BT 5.2, A2DP, HFP, HSP, AVRCP, GATT
Driver (each channel): 40mm x 13.5" speaker driver



Specifications
Model: EP-B22
Technology: BT 5.2, A2DP, HFP, HSP, AVRCP, GATT
Driver (each channel): 40mm x 13.5" speaker driver



Specifications
Model: EP-B22
Technology: BT 5.2, A2DP, HFP, HSP, AVRCP, GATT
Driver (each channel): 40mm x 13.5" speaker driver



Specifications
Model: EP-B22
Technology: BT 5.2, A2DP, HFP, HSP, AVRCP, GATT
Driver (each channel): 40mm x 13.5" speaker driver

