

PB-XD12说明书

AUKEY
Sprint Go 10
取扱説明書

AUKEY製品をお買い上げいただき、誠にありがとうございます。ご使用前にこの取扱説明書をよく読みの上、正しくお使いください。
また、お読みになった後は大切に保管してください。

製品図

- LEDインジケータ
- 電源スイッチ
- USB-C PD 入力/出力
- マイクロUSB入力
- USB Quick Charge 3.0 出力

仕様

モデル	PB-XD12
バッテリータイプ	リチウムポリマー
テクノロジー	Power Delivery, QC3.0
マイクロUSB入力	5V 2A / 9V 2A
USB-C入力	5V 2.6A / 9V 2A
USB-C出力	5-6V 3A / 6-9V 2A / 9-12V 1.5A Power Delivery Supported
USB-A出力1	5-6V 3A / 6-9V 2A / 9-12V 1.5A Quick Charge 3.0 Supported
USB-A出力2	5-6V 3A / 6-9V 2A / 9-12V 1.5A Quick Charge 3.0 Supported
サイズ	98 x 62.5 x 22.5mm
重量	232g
充電サポート	PD2.0 / PD3.0 / PPS / QC2.0 / QC3.0 / FCP / PE / AFC / SFCP

使い方
モバイル/バッテリーへの充電
本製品を初めて使用する前に、下記の手順に従ってモバイル/バッテリー本体をフル充電してください。
・付属のUSB-A to CケーブルをUSB AC充電器(別売)などの電源に接続します。
・ケーブルの両端の端子を本製品のUSB-Cポートに接続します。
・LEDインジケータで充電状況を確認できます。ライトが4つ点灯するまでフル充電されたサインです。

デバイスの充電

- 付属のUSB-A to Cケーブル、またはご使用の機器への充電に対応したケーブル(別売)をご使用の機器の充電ポートに接続します。
※Micro-USBケーブル(別売)はmicroUSB充電ポート搭載の機器のみご使用いただけます。
※ご使用の機器の充電ポートを必ずご確認ください。USB-AポートまたはUSB-Cポートからの給電に対応したケーブルをご用意ください。
- ケーブルのもう一方の端子をモバイル/バッテリー本体のUSB-CポートまたはUSB-Aポートに接続します。
- 電源ボタンを押して充電を開始します。

バッテリー残量
電源ボタンを押して、LEDインジケータで示されたバッテリー残量を確認します。

インジケータ	○○○○●○○○●●○○●●●●●●●●
バッテリー残量	< 25% 25%-50% 51%-75% 76%-99% 100%

●点灯 ○消灯 ○点滅

低電流充電モード
低電流充電モードでは、継続的に低電流での充電を行います。
ワイヤレス充電/スマートフォン/スマートウォッチ/スマートワッチなど600mA未満の低電流デバイスが接続されている場合、2時間の間、低電流で充電を行います。多くの低電流デバイスは2時間以内でフル充電が完了します。

低電流充電モードへの切り替え
本製品を低電流充電モードに切り替えるには、本体の電源スイッチを2秒間長押ししてください。

モードが切り替わるLEDインジケータの1つ目のライトが緑色から白色に変化します。
低電流充電モードの終了
低電流充電モード中に電源スイッチを2秒間長押しすると、低電流充電モードが終了します。低電流充電モード開始から2時間が経過した場合は、低電流充電モードは自動的に終了します。
※モバイル/バッテリー本体の充電中は低電流充電モードへの切り替えはできません。

製品のお手入れと使用上の注意

- 温度が高い場所、極端に高温や低温の場所に長時間放置しないでください。
- モバイル/バッテリー本体を充電している間は、機器を充電しないでください。
- 長期間使用しない場合でも、少なくとも3ヶ月に一度本体を充電してください。
- 強い衝撃を与えないでください。
- 湿気しないでください。
- 車の中に長時間放置しないでください。
- 分解・改造をしないでください。
- 以下の場合には直ちに使用を中止し、サポートセンターにご連絡ください。
- 煙が出ている
- 変形している
- 変色している
- 本製品を廃棄する時は、各自自治体の指示に従った方法で、正しく廃棄してください。

Model: PB-XD12

jp.aukey.com

AUKEYの5つ星の得なお取引先。最新情報をお知らせします。

@AUKEY_jp @AUKEY.jp

AUKEY Technology Co.,Ltd.
jp.aukey.com | japansupport@aukey.com
Room 102, Building P09, South China City
Electronics Trading Center, Longgang District,
Shenzhen, Guangdong, 518111, China

CEFC RoHS Made in China

PBXD12200207A10002E2-H

AUKEY
Sprint Go 10
User Manual

Thank you for purchasing AUKEY products. Please read this user manual carefully and keep it for future reference.

Product Diagram

- LED Indicators
- Power Button
- USB-C Power Delivery Input/Output
- Micro USB Input
- USB Quick Charge 3.0 Output

Specifications

Model	PB-XD12
Battery Type	Lithium Polymer
Technology	Power Delivery, QC3.0
Micro USB Input	5V 2A / 9V 2A
USB-C Input	5V 2.6A / 9V 2A
USB-C Output	5-6V 3A / 6-9V 2A / 9-12V 1.5A Power Delivery Supported
USB-A 1 Output	5-6V 3A / 6-9V 2A / 9-12V 1.5A Quick Charge 3.0 Supported
USB-A 2 Output	5-6V 3A / 6-9V 2A / 9-12V 1.5A Quick Charge 3.0 Supported
Dimensions	98 x 62.5 x 22.5mm 3.85" x 2.46" x 0.89"
Weight	232g / 8.18oz
Charging Protocol Supported	PD2.0 / PD3.0 / PPS / QC2.0 / QC3.0 / FCP / PE / AFC / SFCP

Getting Started
Charge the Power Bank
Please fully charge your power bank before using for the first time:
• Connect included USB-C cable to your USB power source.
• Connect the other end to the USB-C port of the power bank.
• Follow indication light to determine the level of charge. Four light on means fully charged.

Charge Your Devices

- Connect your USB-C or Micro USB cable to your device's charging port.
- Connect another end of the USB-C or Micro USB cable to USB-C or USB-A port on the power bank.
- Press the power button to start charging.

Battery Level
Press the power button to check remaining battery level indicated by the LED indicator.

LED Indicator	○○○○●○○○●●○○●●●●●●●●
Battery Level	< 25% 25%-50% 51%-75% 76%-99% 100%

● On ○ Off ○ Blinking

Low-Current Charging Mode
Means charging at a low current constantly. The power output lasts for 2 hours when a low-power device (below 60mA), such as a Bluetooth headset, fitness band, or smart watch, is connected to it. Most Bluetooth devices can be fully charged within 2 hours.

Activation
Long press power button for 2 seconds, until the first green light of the battery indicator changes from green to white.

Deactivation
Long press power button for 2 seconds to exit the low-current mode, or automatically exit the low-current mode after 2 hours.

Note :
When charging the power bank the low current mode cannot be turned on

Product Care

- Charge your power bank at least once every three months.
- Please keep away from water, liquid, and moisture.
- Keep away from a fire, direct sunlight and extreme heat.
- Dispose of the battery according to local environmental law.
- Do not charge your device while charging the power bank.

Model: PB-XD12

jp.aukey.com

AUKEYの5つ星の得なお取引先。最新情報をお知らせします。

@AUKEY_jp @AUKEY.jp

AUKEY Technology Co.,Ltd.
jp.aukey.com | japansupport@aukey.com
Room 102, Building P09, South China City
Electronics Trading Center, Longgang District,
Shenzhen, Guangdong, 518111, China

CEFC RoHS Made in China

PBXD12200207A10002E2-H

通知部門	
設計	
產品	
文案	
市場	
銷售	
開發	

PB-XD12说明书要求

- 材质: 128G双铜;
印刷颜色: 1专(PANTONE 2240C)+黑色, 双面印刷;
折法: 风琴折, 7折;
成品尺寸: 50x75mm,
展开尺寸: 400x75mm

AUKEY		傲基科技股份有限公司 Aukey Technology Co.,Ltd	
品 牌	AUKEY		
产品名称(型号)	PB-XD12		
SKU			
制 图 人			
日 期	20200322		
版 本 号	PBXD12200207A10002E2-M	版本更新日期	20210712
电子工程师审核			
产品总监			