Model: EP-T10

FCC ID: 2AP4P-EPT10 IC: 24135-EPT10
Shenzhen AUKEY E-Business Co., Ltd.
Shenzhen AUKEY Business Development Co.
No.132 Building F3B, Electronics Trade Center
Shenzhen City, Pingdi Town, Longgang District
Shenzhen, Guangdong 518118 CN

Made in China

AUKEY

User Manual
True Wireless Earbuds

Contents

English ..... 01 – 12
Deutsch ..... 13 – 24
Français ..... 25 – 36
Español ..... 37 – 48
Italiano ..... 49 – 60
日本語 ..... 61 – 68

说明书尺寸：75x100mm
材质：105g铜版纸
印刷：单黑
装订方式：骑马钉

Thank you for purchasing the AUKEY EP-T10 True Wireless Earbuds. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

Package Contents

Left Wireless Earbud
Charging Case
Three Pairs of Ear Buds (S/M/L)
USB-C to USB-A Charging Cable (USB-A to C Cable)
User Manual
Warranty Card

Product Diagram

Specifications

Earbuds	
Model	EP-T10
Technology	Bluetooth 5, A2DP, AVRCP, HFP, HSP, SBC, AAC
Driver (each channel)	6 mm, Dynamic driver
Sensitivity	94 ± 3 dB SPL @ 1 kHz
Frequency Range	20Hz - 20kHz
Impedance	16 ohm ±10%
Microphone Type	Dual Microphone (Top)
Microphone Sensitivity	-42dB ±3dB
Charging Time	1.5 hours
Playtime	Up to 4 hours
Battery Type	Lithium-ion (3 x 50mAh)
Operating Range	Up to 10m / 33'
Weight	3.7g/ea (pair)
IP Rating (earbuds)	IPX4

Charging Case	
Charging Input	DC 5V
Charging Time	1.5 hours
Battery Type	Lithium-ion (480mAh)
Number of Earbuds Recharges	3 More (pcs)
Weight	41g / 2.15oz

Getting Started

Remove the charging case from the case before first use. Connect the charging case to a USB charger or charging port with the included USB-A to C cable. Or use a wireless charger (QI). Keep the charging case charged. When the charging indicator turns solid white, the charging case is fully charged. When the charging indicator turns solid red, the earbuds in the charging case. After fitting fully charged, the case can fully charge the earbuds in the charging case. When the charging indicator turns solid white, the charging indicator will turn white for 30 seconds and then turn off. The LED status indicator will flash red when the battery is low. When the earbuds are charging, the LED status indicator turn off. The earbuds are fully charged. The charging indicator will flash white when the charging case has low power.

Turning On / Off

Open the charging case and take out the left and right earbuds simultaneously from the charging case. Turn Off: Put the left and right earbuds back into the charging case.

Pairing

1. Take out the left earbuds in the case.
2. Take out the left and right earbuds simultaneously. They will turn on automatically and connect with each other within 10 seconds.
3. Enable Bluetooth on your device and search for "AUKEY EP-T10" to pair. Pairing with one earbud is also supported. Take out the left earbud and the LED status indicator on the right earbud will flash red and blue. The indicator the earbud will ready to pair. Enable Bluetooth on your device and search "AUKEY EP-T10" to pair.
4. If a pop-up window appears, tap "Connect" to complete the pairing.
5. Enjoy your music or calls.

Regular Use After Pairing

Once the earbuds are successfully paired with your device, each time you want to use them, simply take out the earbuds and they will automatically connect to your device.

To power on, simultaneously take the earbuds out from the charging case and they will turn on automatically.

Using the Right Earbud Only

1. Take out the earbud in the case.
2. Pair with your device.
3. You will hear a "pairing" voice notification, and the LED status indicator on the earbud will flash red and blue.
4. Turn on the pairing function on the device you want to pair with the earbud.
5. In the list of available devices, find and select "AUKEY EP-T10".

Notes

- The right earbud is the master unit. The left earbud can't be used independently.
- If the left earbud is lost or damaged, the right earbud can still connect to the last paired device or enter pairing mode if no paired device is found.
- To clear the pairing list: touch and hold the multi-function button on the right earbud for 10 seconds when the earbuds are in the charging case. The LED status indicator will flash 3 times.

- If the left and right earbuds don't connect with each other, touch and hold the multi-function button on both earbuds for 5 seconds. You will hear a tone when the left and right earbuds are connected successfully.
- If the left earbud can't connect to the device after 5 minutes in pairing mode, it no longer will attempt to pair.
- If the right earbud is in pairing mode, double-tap the multi-function button on the right earbud.
- Turn off the Bluetooth function on your device.
- Turn on the pairing function on the device you want to pair with the earbud.
- The maximum wireless operating range is 10m (33ft). If you exceed this range, the connection will be automatically terminated. When you return to the effective range, the connection will be re-established once you re-enter the wireless range within 5 minutes. The earbuds will automatically reconnect to the last paired device. To connect with other devices, repeat the previous "Pairing" steps.

Controls & LED Indicators

Volume Control
Music Control
Call Control

Volume Control: Adjust volume on both earbuds from your device to the earbuds. Music will automatically pause when you receive an incoming phone call and resume once the call is ended.

Play or pause	Tap the multi-function button on either earbud
Increase volume	Long hold the multi-function button on the right earbud
Decrease volume	Long hold the multi-function button on the left earbud
Skip to next track	Double tap the multi-function button on the right earbud
Skip to previous track	Double tap the multi-function button on the left earbud

Answer an end a call	Tap either earbud multi-function button once. If there's a second incoming call, tap the multi-function button once to answer the second call and hold the multi-function button for 2 seconds to answer the second call and put the first call on hold. Then tap either earbud multi-function button once. If there's a second call on hold, between these two calls.
Reject an incoming call	Touch and hold either earbud multi-function button for 2 seconds.
Switch between the two calls	Tap the multi-function button on either earbud

Reject or end a call	Tap either earbud multi-function button for 2 seconds.

Taking Calls

Tap either earbud multi-function button once. If there's a second incoming call, tap the multi-function button once to answer the second call and hold the multi-function button for 2 seconds to answer the second call and put the first call on hold. Then tap either earbud multi-function button once. If there's a second call on hold, between these two calls.

Touch and hold either earbud multi-function button for 2 seconds.

Tap the multi-function button on either earbud

Status	
Flashing red and blue	Pairing mode (Waiting to pair)
Solid white	Connected / Playing music
White flashing every 5 seconds	Standby
Solid red	Charging
Flashing red	Low voltage

LED Charging Indicator (Charging case)	Status
Solid white for 30 seconds	Charging earbuds
White flashing every 5 seconds	Standby
White flashing every one second	Charging
Solid red	Low voltage

FAQ

The earbuds are on but not connecting to my device
Make sure the earbuds are connected to your device. If not, you need to pair them both in pairing mode. Please follow the instructions in the "Pairing" section of the manual.

My device can't find "AUKEY EP-T10" on the pairing list when trying to pair
Make sure the earbuds are in pairing mode (right earbud flashes white and red). See the "Pairing" section of the manual. Otherwise, restart your device and the earbuds then try pairing again.

I've established a connection with my smartphone but can't hear any sound
Troubleshooting: Ma volume level on your smartphone and the earbuds. Some smartphones require you to set up the earbuds as an audio output device before receiving audio from them. Also, playing music/a video or other device, please make sure it supports the A2DP profile.

The sound isn't very clear or the caller can't hear my voice clearly
Adjust the volume on your smartphone. Try getting closer to your smartphone to rule out any Bluetooth connection issues. Some applications range-related issues.

Product Care & Use

- Keep away from extreme heat and strong magnetic fields
- Do not attempt to disassemble, drop, crush or puncture your earbuds
- Do not use chemicals, cleaners or aerosols to clean the earbuds

Warranty & Customer Support

We guarantee a period of warranty (varies by country) on all the products below that correspond with your region. Please include your Amazon order number and product model number.

Amazon US orders: support.anker.com
Amazon EU orders: support.anker.com
Amazon CA orders: support.anker.com
Amazon JP orders: support.anker.jp
Amazon AU orders: support.anker.com.au

These rules AUKEY can only provide after sale service to products purchased directly from AUKEY. If you have any questions about your product, please contact them directly for service or warranty issues.

Notice for the US

Cable and accessories: Do not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Let present equipment operate on some CAR (Module Complo applicable (ex: equipment radio example de horaire / separation set outside (ex: deux conditions sonores).
1. Interference nuisible ne doit pas être causée.
2. Il ne faut pas que l'appareil soit exploité tout en subiste nuisible, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CE Statement

Hoja EP power lever
Hoja EP power lever(pulgada): 3.18in
EP exercise equipment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation (1999/519/EC).

Trademark

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Anker Innovations Limited is under license. Other trademarks and trade names are those of their respective owners.

CAUTION RIK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Excessive sound pressure from earphones and headphones can cause hearing loss.

Shenzhen AUKEY E-Business Co., Ltd. declares that the radio equipment type (Five Pairs of Ear Buds (S/M/L)) is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.aukey.com

Notice: This device may be used in each member state of the EU.

Hiermit erklärt AUKEY E-Business Co., Ltd. dass die Funkanlagenbauart (Five Pairs of Ear Buds (S/M/L)) mit Richtlinie 2014/53/EU konform ist. Der vollständige Text der EU-Konformitätserklärung ist auf folgender Website verfügbar: www.aukey.com.

Hinweis: Dieses Gerät darf in jedem EU-Mitgliedstaat verwendet werden.

Produktbild

Technische Daten

Ohrhörer	
Modell	EP-T10
Technologie	Bluetooth 5, A2DP, AVRCP, HFP, HSP, SBC, AAC
Treiber (jeder Kanal)	6 x 6 mm Lautsprecher
Empfindlichkeit	94 ± 3 dB SPL bei 1 kHz (1 mW)
Frequenzbereich	20Hz-20kHz
Impedanz	16 Ohm ±10%
Mikrofontyp	Dual Mikrofon (Top)
Mikrofonempfindlichkeit	-42 dB ±3 dB
Ladezeit	1,5 Stunden
Akkuleistung	Bis zu 4 Stunden
Batterietyp	Lithium-Polymer (3 x 50 mAh)
Betriebsbereich (Ohrhörer)	Bis zu 10m
Betriebsdauer	Bis zu 10m/33'
Gewicht	3,7g/Ohrhörer (Paarweise)

Ladestation	
Ladeeingang	5 V (Gleichstrom)
Ladezeit	1,5 Stunden
Batterietyp	Lithium-Polymer (480mAh)
Ladezyklen	3 mal (Earbuds Ohrhörer)
Gewicht	41 g

Erste Schritte

Entfernen Sie das Ladegerät vor der ersten Verwendung vollständig aus. Verbinden Sie das Ladegerät mit einem USB-Ladegerät oder -Ladeanschluss. Es können auch kabellose Ladegeräte verwendet werden. Sie können das Ladegerät jederzeit aufladen. Wenn das Ladegerät vollständig geladen ist, leuchtet die Ladeanzeige weiß. Wenn die Ohrhörer im Ladegerät vollständig geladen sind, leuchtet die Ladeanzeige rot. Wenn das Ladegerät vollständig geladen ist, leuchtet die Ladeanzeige weiß und erlischt nach 30 Sekunden. Die Ladeanzeige blinkt rot, wenn der Akkustand des Ladegerätes niedrig ist. Wenn das Ladegerät aufgeladen ist, erlischt die Ladeanzeige. Wenn das Ladegerät aufgeladen ist, können die Ohrhörer im Ladegerät vollständig geladen. Die Ladeanzeige blinkt weiß, wenn der Akkustand des Ladegerätes niedrig ist.

Ein-/Ausschalten

Entnehmen Sie gleichzeitig das linke und das rechte Ohrhörer aus dem Ladegerät. Ausschalten: Legen Sie die Ohrhörer in das Ladegerät zurück.

Pairing

1. Entnehmen Sie das linke Ohrhörer.
2. Nehmen Sie den linken und rechten Ohrhörer gleichzeitig aus dem Ladegerät. Sie werden automatisch ein und verbinden sich innerhalb von 10 Sekunden miteinander.
3. Aktivieren Sie die Bluetooth-Funktion Ihres Geräts und suchen Sie nach "AUKEY EP-T10" zum Koppeln. Das Koppeln mit einem Ohrhörer wird auch unterstützt. Nehmen Sie das linke Ohrhörer heraus. Das linke Ohrhörer und der rechte Ohrhörer blinken rot und blau. Das linke Ohrhörer ist bereit zum Koppeln. Aktivieren Sie die Bluetooth-Funktion Ihres Geräts und suchen Sie nach "AUKEY EP-T10" zum Koppeln.
4. Wenn Sie in der Liste verfügbarer Geräte „AUKEY EP-T10" sehen, wählen Sie „AUKEY EP-T10" aus und tippen Sie auf „Verbinden" oder „Koppeln".
5. Genießen Sie Ihre Musik oder Anrufe.

Normale Verwendung nach dem Pairing

Wenn die Ohrhörer mit Ihrem Gerät erfolgreich verbunden sind, müssen Sie diese jedes Mal, wenn Sie sie verwenden, lediglich aus dem Ladegerät herausnehmen und sie werden automatisch mit Ihrem Gerät verbunden.

Um sie einzuschalten, nehmen Sie sie einfach aus dem Ladegerät heraus.

Verwendung des rechten Ohrhörers

1. Nehmen Sie den rechten Ohrhörer heraus.
2. Sie hören ein akustisches „Pairing" Signal und die LED-Statusanzeige des Ohrhörers blinkt rot und blau.
3. Aktivieren Sie die Pairing-Funktion auf dem Gerät, das Sie mit dem Ohrhörer koppeln wollen.
4. Wählen Sie in der Liste verfügbarer Geräte „AUKEY EP-T10" aus.

Hinweise

- Das rechte Ohrhörer ist der Master Ohrhörer. Das linke kann nicht allein verwendet werden.
- Wenn das linke Ohrhörer verloren oder beschädigt ist, können Sie das rechte Ohrhörer weiterhin mit dem zuletzt gekoppelten Gerät verbinden oder es in den Pairing-Modus versetzen, wenn kein gekoppeltes Gerät vorhanden ist.
- Um die Kopplungsliste zu löschen: Tippen und halten Sie die Multifunktionstaste am rechten Ohrhörer 10 Sekunden lang, wenn sich die Ohrhörer im Ladegerät befinden. Die LED-Anzeige blinkt dann 3 mal.
- Die Ohrhörer schalten sich nach 5 Minuten im Pairing-Modus automatisch aus, wenn sie innerhalb dieser Zeit nicht gekoppelt sind.
- Falls an einem der Ohrhörer kein Ton zu hören ist, legen Sie beide Ohrhörer in das Ladegerät und nehmen Sie sie erneut heraus.
- Wenn Sie Ihr Gerät nach dem Pairing wieder verbinden, müssen Sie lediglich diesen Bluetooth-Vorgang ausführen, um die Verbindung zu Ihrem Gerät zu aktivieren.
- Falls das Pairing-Verfahren der Ohrhörer nicht erfolgreich ist, drücken Sie zweimal auf die Multifunktionstaste des rechten Ohrhörers.
- Zum Löschen der Pairing-Liste drücken und halten Sie die Multifunktionstaste am rechten Ohrhörer 10 Sekunden lang, wenn sich die Ohrhörer im Ladegerät befinden. Die LED-Anzeige blinkt dann 3 mal.
- Die Ohrhörer schalten sich nach 5 minuten im Pairing-Modus automatisch aus, wenn sie innerhalb dieser Zeit nicht gekoppelt sind.
- Falls an einem der Ohrhörer kein Ton zu hören ist, legen Sie beide Ohrhörer in das Ladegerät und nehmen Sie sie erneut heraus.
- Wenn Sie Ihr Gerät nach dem Pairing wieder verbinden, müssen Sie lediglich diesen Bluetooth-Vorgang ausführen, um die Verbindung zu Ihrem Gerät zu aktivieren.
- Falls das Pairing-Verfahren der Ohrhörer nicht erfolgreich ist, drücken Sie zweimal auf die Multifunktionstaste des rechten Ohrhörers.

Steuerungsfunktionen & LED-Anzeigen

Audio Streaming

Wenn Sie Ihr Gerät mit Ihrem Ohrhörer gekoppelt haben, können Sie Musik und Anrufe über Ihre Ohrhörer abspielen. Wenn ein Anruf ungeht, wird die Musik automatisch unterbrochen. Sobald der Anruf beendet ist, wird die Musik automatisch wieder fortgesetzt.

Verwendung nur des rechten Ohrhörers

Sie können nur das rechte Ohrhörer verwenden.

Sie können ein akustisches „Pairing" Signal und die LED-Statusanzeige des Ohrhörers blinken rot und blau.

Aktivieren Sie die Pairing-Funktion auf dem Gerät, das Sie mit dem Ohrhörer koppeln wollen.

Wählen Sie in der Liste verfügbarer Geräte „AUKEY EP-T10" aus.

Hinweis: Die rechte Ohrhörer ist der Master Ohrhörer. Das linke kann nicht allein verwendet werden.

Wenn Sie Ihr Gerät nach dem Pairing wieder verbinden, müssen Sie diese jedes Mal, wenn Sie sie verwenden, lediglich aus dem Ladegerät herausnehmen und sie werden automatisch wieder verbunden.

Um sie einzuschalten, nehmen Sie sie einfach aus dem Ladegerät heraus.

Um sie auszuschalten legen Sie die Ohrhörer in das Ladegerät zurück