AUKEY

Sprint Wireless 10
取扱説明書

AUKEY製品をお買い上げいただき、誠にありがとうございます。
ご使用前にこの取扱説明書をよくお読みの上、正しくお使いください。また、お読みになった後は大切に保管してください。

パッケージ内容

本体
USB-C to C ケーブル
取扱説明書
保証書

製品図



バッテリー残量

電源ボタンを押すとLEDインジケータが点灯または点滅して現在のバッテリー残量を表示します。LEDインジケータが示す状態は以下のとおりです。

インジケータ	○○○○	●○○○	●●○○	●●●○	●●●●
バッテリー残量	< 25%	25%~50%	51%~75%	76%~99%	100%

● 点灯　○ 消灯　◎ 点滅

製品仕様

型番	PB-Y32S
テクノロジー	Qi, USB Power Delivery3.0, Qualcomm®Quick Charge 3.0
容量	10000mAh / 38.5wh
バッテリータイプ	リチウムポリマー
Micro-USB入力	DC 5V 2A / 9V 2A / 12V 1.5A
USB-C入力	(PD 3.0) DC 5V 2.6A / 9V 2A / 12V 1.5A
USB-C出力	(PD 3.0) DC 5V 3A / 9V 2.22A / 12V 1.67A
USB-A出力	(QC 3.0) DC 5V 3A / 9V 2A / 12V 1.5A; (SCP) 4.5V 5A / 5V 4.5A
ワイヤレス出力	5W / 7.5W / 10W / 15W
最大出力	22.5W
合計出力	DC 5V 3A (15W)
寸法	144 x 67 x 17mm
重量	227g
使用温度範囲	0~40℃
保管温度範囲	5~50℃

本体への充電方法

初めて使用する前に、本体を完全に充電してください。
1. 付属のUSB-C to Cケーブルまたは Micro-USBケーブル（別売）をUSB充電器（別売）などの電源に接続します。
2. もう一方の端を本体のUSB-CまたはMicro-USBポートに接続します。
3. LEDインジケーターで充電レベルを確認できます。完全に充電されるとランプが４点灯します。

※本体を充電している間も、ワイヤレス充電が可能です。

機器への充電方法

ワイヤレス充電

1. 電源ボタンを1回押すと、ワイヤレス充電モードに入り、ワイヤレス充電インジケーターが青色に点灯します。
2. ワイヤレス充電エリアにQi対応機器を置きます。
3. フル充電されたら、ワイヤレス充電エリアから機器を取り除きます。

- ワイヤレス充電モードをONにすると、はじめは5Wの出力がスタートします。USB-AまたはUSB-Cポートに何も接続されていない場合、その後7.5W（iPhoneの場合）または10W/15Wまで出力が自動的に増加します。
- USB-AまたはUSB-Cポートで機器の充電 充電を行っている場合でも、電源ボタンを押すとワイヤレス充電モードをONにすることができます。
- その場合、ポート（有線）でのデバイス充電出力は5V 3A(15W)までに制限されます。ワイヤレス充電モードでQi対応機器 が検出されない場合、15秒後に自動的にワイヤレス充電モードが終了し、USB-AまたはUSB-Cポートからの急速充電が再開します。

有線充電

1. 充電ケーブルを機器の充電ポートに接続します。
2. もう一方の端を本体のUSB-AまたはUSB-C出力ポートに接続します。
3. フル充電されたら、機器を取り外します。

本製品で２つの機器を同時に充電する場合の出力は、5V3A（15W）までに制限され、急速充電ではなく標準速度での充電になりますのでご注意ください。同時充電からUSB-C(PD)ポートの みでの充電に切り替えた場合、10秒後に標準速度から急 速充電に切り替わります。

製品のお手入れと使用上の注意

- 本製品はMicro-USBポートとUSB-Cポートで同時に電源入力を行うことはできません。
- 湿度が高い場所、極端に高温や低温の場所に長時間放置しないでください。
- 長期間使用しない場合でも、少なくとも3ヶ月に1度本体を充電してください。
- 落下など、強い衝撃を与えないでください。
- 加熱しないでください。
- 車の中に長時間放置しないでください。
- 分解・改造をしないでください。
- 乳幼児の手の届かない所で使用してください。
- 以下の場合は直ちに使用を中止し、サポートセンターにご連絡ください。
  ー煙が出ている
  ー変な匂いがする
  ー変形している
- 本製品を廃棄する時は、各自治体の指示に従った方法で、正しく廃棄してください。

Model: PB-Y32S

jp.aukey.com

AUKEYからのお得なお知らせ、最新情報をお届けします。

@AUKEY_jp　@Aukey.jp
@Aukey.jp　AUKEY JAPAN

AUKEY Technology Co., Ltd.
jp.aukey.com | japansupport@aukey.com
Room 102, Building P09, South China City
Electronics Trading Center, Longgang District,
Shenzhen, Guangdong, 518111, China

RoHS Made in China

株式会社美貴本

AUKEY

Sprint Wireless 10
User Manual

Thank you for purchasing AUKEY products.
Please read this user manual carefully and keep it for future reference.

Package Contents

Sprint Wireless 10
USB-C to C Cable
User Manual
Warranty Card

Product Diagram



Battery Level

Press the power button to check remaining battery level indicated by the LED indicator.

LED Indicator	○○○○	●○○○	●●○○	●●●○	●●●●
Battery Level	< 25%	25%~50%	51%~75%	76%~99%	100%

● On ○ Off

Specifications

Model	PB-Y32S
Technology	Qi, USB Power Delivery3.0, Qualcomm®Quick Charge 3.0
Capacity	10000mAh / 38.5wh
Battery Type	Lithium polymer
Micro-USB Input	DC 5V 2A / 9V 2A / 12V 1.5A
USB-C Input	(PD3.0) DC 5V 2.6A / 9V 2A / 12V 1.5A
USB-C Output	(PD3.0) DC 5V 3A / 9V 2.22A / 12V 1.67A
USB-A Output	(QC 3.0) DC 5V 3A / 9V 2A / 12V 1.5A; (SCP) DC 4.5V 5A / 5V 4.5A
Wireless Output	5W / 7.5W / 10W / 15W
Max Power Output	22.5W
Multi-Port Output	DC 5V 3A (15W)
Dimensions	144 x 67 x 17mm 5.67" x 2.64" x 0.67"
Weight	227g / 8.01oz
Temperature Range	Operating: 0～40℃
	Storage: 5～50℃

Getting Started

Charging the Power Bank

1. Connect the included USB-C to C cable or your own micro-USB cable to a USB charger or charging port.
2. Connect the other end to the USB-C / micro-USB input port on the power bank.
3. Unplug the power bank when fully charged.

Note

The power bank supports wireless charging while it's being recharged

Charging Your Device

Wireless Charging

1. Press the power button on the power bank once to enter wireless charging mode. The wireless charging indicator will blink orange.
2. Put your Qi-compatible phone on the power bank (the lightning bolt icon side).
3. Remove your phone when fully charged.

Notes

- When the wireless charging mode is turned on, wireless charging will begin at 5W. If no devices are connected to the USB or USB-C port, output will automatically increase to **7.5W or 10W or 15W** for compatible wireless fast charging devices after 15 seconds.
- If you press the power button to enter wireless charging mode while the USB or USB-C port is fast-charging your device, the output on that port will be limited to 5V 3A (15W). The power bank automatically exits wireless charging mode after 15 seconds if no Qi device is detected, and the USB or USB-C port will resume fast charging.

Wired Charging

1. Connect the included USB-C to C cable or your own micro-USB cable to your device charging port.
2. Connect the other end to the USB-C or USB output port on the **PB-Y32S.**
3. Unplug your device when fully charged.

Note

The power bank can't fast charge two devices simultaneously due to the maximum **multi-port power** output of **15W**. When switching from standard speed dual charging to USB PD only fast charging, fast charging will begin after 10 seconds.

Notes

- Wireless charging and low-current charging mode can't be used simultaneously.
- The USB-C port can continue to fast-charge devices while the USB port is being used in low-current charging mode.
- When the power bank is in low-current charging mode, the USB port won't fast-charge. To enable USB port fast charging, exit low-current charging mode.

Product Care & Use

- Keep away from liquids and extreme heat.
- Recharge the **PB-Y32S** at least once every 3 months.
- The **PB-Y32S** doesn't accept simultaneous micro-USB and USB-C power input.
- Dispose of battery according to local environmental law.

Model: PB-Y32S

jp.aukey.com

AUKEYからのお得なお知らせ、最新情報をお届けします。

@AUKEY_jp　@Aukey.jp
@Aukey.jp　AUKEY JAPAN

AUKEY Technology Co., Ltd.
jp.aukey.com | japansupport@aukey.com
Room 102, Building P09, South China City
Electronics Trading Center, Longgang District,
Shenzhen, Guangdong, 518111, China

RoHS Made in China

株式会社美貴本

材质：128G双铜;
印刷颜色:1专(PANTONE 2240C)+黑色, 双面印刷;
折法：风琴折
成品尺寸:50x75mm,
展开尺寸:500x75mm